

Manual Supplement

Manual Title: 123B/124B/125B Users
Print Date: January 2016
Revision/Date:

Supplement Issue: **5**
Issue Date: 10/22
Page Count: 1

This supplement contains information necessary to ensure the accuracy of the above manual.




Change #1, 257

On page 54, replace step 9 with:

9. Push **ENTER** and use **▲▼** and **ENTER** to set the percentage of deviation for time (relative to 1 period) and the amplitude deviation (relative to peak-to-peak) for waveforms. Threshold can be used for signals up to 4 kHz.

Change #2, 380

On the Cover, add the  Symbol.

Change #3, a272, 676

On page 72, under **Input A and Input B**, for DC Voltage (VDC) replace Accuracy with:

Accuracy $\pm(0.5 \% + 5 \text{ counts})$ with noise filter OFF, no signal applied, after AUTOSET, and the ground level moved to the center grid line.